

Spring Pre-rotation Chart Z-Screen Fabric 5% opening

RS-C04, left side spring 1-1/4"

| Drop Length | Shade Width | |
|-------------|-------------|-----|
| | inches | |
| 48" | 32" | 36" |
| 60" | 15 | 17 |
| 72" | 17 | 19 |
| 84" | 19 | |
| 96" | | |

Weight of bottom bar + fabric should be between:
1.1 lbs (500g.) and 2.64 lbs (1200 g.). **Not exceed 2.64 lbs(1200g.)**

RS-C05, left side spring 1-1/2"

| Drop Length | Shade Width | | | |
|-------------|-------------|-----|-----|-----|
| | inches | | | |
| 48" | 32" | 36" | 48" | 60" |
| 60" | 10 | 11 | 14 | 17 |
| 72" | 11 | 13 | 16 | |
| 84" | 13 | 14 | 18 | |
| 96" | 14 | 16 | | |

Weight of bottom bar + fabric should be between:
1.1 lbs (500g.) and 4.18 lbs (1900 g.). **Not exceed 4.18 lbs(1900g.)**

RS-C67, left side spring 1-1/4"

| Drop Length | Shade Width | | |
|-------------|-------------|-----|-----|
| | inches | | |
| 48" | 36" | 48" | 60" |
| 60" | 9 | 13 | 17 |
| 72" | 10 | 13 | 18 |
| 84" | 10 | 14 | 18 |
| 96" | 12 | 15 | 18 |

Weight of bottom bar + fabric should be between:
1.1 lbs (500g.) and 5.5 lbs (2500g.). **Not exceed 5.5 lbs(2500g.)**

RS-C56, left side spring 1-1/2"

| Drop Length | Shade Width | | | | | |
|-------------|-------------|-----|-----|-----|-----|-----|
| | inches | | | | | |
| 48" | 36" | 48" | 60" | 72" | 84" | 96" |
| 60" | | | 7 | 9 | 10 | 12 |
| 72" | | 6 | 8 | 10 | 13 | 15 |
| 84" | | 7 | 10 | 12 | 15 | |
| 96" | 6 | 9 | 11 | 14 | | |

Weight of bottom bar + fabric should be between:
3.7lbs (1700g.) and 8.2 lbs (3700g.). **Not exceed 8.2 lbs(3700g.)**

RS-C62, RIGHT side spring 1-1/4"

| Drop Length | Shade Width | | |
|-------------|-------------|-----|-----|
| | inches | | |
| 36" | 24" | 30" | 36" |
| 48" | 8 | 10 | 12 |
| 60" | 10 | 12 | 14 |
| | | | |
| | | | |

Weight of bottom bar + fabric should be between:
0.7 lbs (300g.) and 2.2 lbs (1000g.). **Not exceed 2.2 lbs(1000g.)**

RS-C61, RIGHT side spring 1-1/4"

| Drop Length | Shade Width | | |
|-------------|-------------|-----|-----|
| | inches | | |
| 24" | 16" | 20" | 24" |
| 30" | 6 | 7 | 8 |
| 36" | 7 | 8 | 10 |
| | | | |
| | | | |

Weight of bottom bar + fabric should be between:
0.4 lbs (200g.) and 1.1 lbs (500g.). **Not exceed 1.1 lbs(500g.)**

- Note:-
- 1.- Use this chart as a guideline only. It is based on fabric weight of 0.16lb/sq.feet and bottom bar weight of 0.18lbs/ft. Each blind must be checked after assembly to confirm that it functions properly.
 - 2.- If fabric used is lighter that the one used in this chart, the turns should be less.
 - 3.- Do not choose heavy fabrics. If the fabric is too heavy , choose a light bottom bar.
 - 4.- For big and heavy blinds use the slower speed.
 - 5.- Choose the correct tube and spring size (according to the weight range of the spring).
 - 6.- For right side mechanisms, pre-load the spring in an counter-clockwise direction.